

Shopcam Installation Guide

Thank you for your recent purchase of Shopcam. How you install the software will depend on the software protection you chose. Select from the three below.



NOTE: If the actual hard-lock device is backordered, install per (*a: Subscription Code*) and we will issue a temporary code. Follow the instructions when the hard-lock arrives.

You do not need to uninstall Shopcam prior to installing the new revision.

A: Subscription Code

With this method, fax or email the site code to us at 989-662-2640. An authorization code will be faxed back. Notice the expiration section. This is simply for reminding you when the software is due to expire and starts notifying you to request a new number. It has absolutely no effect on the actual expiration. You may adjust the [Start warning] days per your preference.



B: USB port Hard-lock

Do not plug in the hard-lock until after the Shopcam software has been installed. Once installed, insert the hardlock into a USB port and follow the 'New hardware' instructions from the operating system.




C: Parallel port Hard-lock

Plug this hardlock into the parallel/printer port prior to installing the Shopcam software.

If you already have the system installed, close ShopCAM, plug the hardlock into the parallel/printer port. Run the following file:

```
C:\program files\dbs\shopcam\donglefiles\INSTALL_HL_DRIVER.EXE
```

A message box with "Dongle setup completed" will appear. Then start ShopCAM.



If you have any questions, don't hesitate to call.